



## ***Operators check list – Speedwash range***

### **Set-up Procedure...**

- Ensure that there is **detergent** and **rinse-aid** in the containers and that the feed pipes are submerged in the chemicals, that the filters, wash/rinse arms and drain plug (where fitted) are in place.

### ***ENSURE THAT WASH/RINSE ARMS ROTATE FREELY!***

- Close machine door. Switch **ON** power to machine at isolator/plug socket.
- Switch the machine **ON (0-1 button)**. The machine will automatically fill with water. Allow 30 minutes or longer to heat up rinse and wash water tanks.

### **Operating Machine...**

- **Remove food scraps and debris from the crockery/cutlery before loading in basket.**
- Ensure that all cups/bowls are placed upside down in the basket and that the dishes are placed in the rack facing the same way. Cutlery should be placed in a cutlery basket, handle first; ensuring small handles cannot drop through and foul arms.

### ***DO NOT OVERLOAD BASKET!***

- Load basket in machine. Where appropriate, select cycle option.
- Press the programme start button to **start** the wash/rinse cycle.
- Once the wash/rinse cycle is complete, open door and remove basket to allow contents to dry.
- Close door or load next basket, then close door for next cycle.

### **Shut-down Procedure...**

- Switch the machine **OFF (0-1 button)**.
- Remove drain plug (where fitted, lifting filter if required) and allow to empty, or close door and press/hold in **drain pump button** (where fitted) until tank is empty.

### ***DO NOT REMOVE FILTERS UNTIL MACHINE IS EMPTY!***

- Switch **OFF** power to machine at isolator/plug socket.
- Remove and clean remaining filter/s. Remove and clean wash/rinse arms as required. Remove any debris from tank.
- Replace filter/s and wash/rinse arms.

### **For Machines with Built In Water Softeners – To be done every day machine is in use...**

#### ***REFILL SALT CONTAINER DAILY!***

- Unscrew salt container lid and fill with **granulated salt** (some water will be displaced). Ensure seal is clean and replace lid.
- Switch **Off** power to machine at **On/Off** switch.
- Close the door and then press the **regeneration button ("S" symbol)** until the light stays illuminated. The regeneration cycle will last approximately 20 minutes and the light will go out when complete. Please ensure drain plug is **NOT** in machine when carrying out regeneration cycle.
- Open door and flush away any residual salt. If necessary, refill wash tank and then empty to clear thoroughly.
- Switch **ON** power to machine at isolator/plug socket, or go through set up procedures if at start of day.

***The machine is now ready for the usual start-up procedure.***

**FOR SERVICE, CHEMICALS OR ADVICE, CALL US ON 020 8993 6198**