



Operators check list – Speedclean range

Set Up Procedure...

- Ensure that there is **detergent** and **rinse-aid** in the containers and that the feed pipes are submerged in the chemicals, that the filters, wash/rinse arms and drain plug (where fitted) are also correctly in place.

ENSURE THAT WASH/RINSE ARMS ROTATE FREELY!

- Close machine door. Switch **ON** power to machine at isolator/plug socket.
- Switch the machine **ON (0-1 button)**. The machine will automatically fill with water. Allow 30 minutes or longer to heat up rinse and wash water tanks.

Operating Machine...

- ***Remove dregs/debris from the glassware before loading in basket.***
- Ensure that all glassware is placed upside down in the basket. Stirrers and smaller items should be placed in the provided holder. Ensure that nothing can drop through and foul arms.

DO NOT OVERLOAD BASKET!

- Load basket/rack in machine. Where appropriate, select cycle option.
- Press the programme start button to **start** the wash/rinse cycle.
- Once the wash/rinse cycle is complete, open door and remove basket to allow contents to dry.
- Close door or load next basket, then close door for next cycle.

Shut-down Procedure...

- Switch the machine **OFF (0-1 button)**.
- Remove drain plug (where fitted, lifting filter if required) and allow to empty, or close door and press/hold in **drain pump button** (where fitted) until tank is empty.

DO NOT REMOVE FILTERS UNTIL MACHINE IS EMPTY!

- Switch **OFF** power to machine at isolator/plug socket.
- Remove and clean remaining filter/s. Remove and clean wash/rinse arms as required. Remove any debris from tank.
- Replace filter/s and wash/rinse arms.

For Machines with Built In Water Softeners – To be done every day machine is in use...

REFILL SALT CONTAINER DAILY!

- Unscrew salt container lid and fill with **granulated salt** (some water will be displaced). Ensure seal is clean and replace lid.
- Switch **OFF** power to machine at **On/Off** switch.
- Close the door and then press the **regeneration button ("S" symbol)** until the light stays illuminated. The regeneration cycle will last approximately 20 minutes and the light will go out when complete. Please note the Drain plug must be **OUT** of the machine when carrying out regeneration cycle.
- Switch **ON** power to machine at isolator/plug socket, or go through set up procedures if at start of day.

The machine is now ready for the usual start-up procedure.

FOR SERVICE, CHEMICALS OR ADVICE, CALL US ON 020 8993 6198